



# PLUTO Safety-PLC

## Operating instructions

### Hardware

## Table of contents:

1	General .....	3
2	Enclosure .....	4
3	Electrical installation.....	4
4	Inputs and outputs.....	5
4.1	I.. Digital failsafe inputs .....	8
4.2	IQ.. Digital failsafe inputs / Digital outputs (non failsafe).....	9
4.2.1	Dynamic signals .....	9
4.2.2	Current monitoring IQ16, IQ17 (Only A20).....	9
4.3	Analogue inputs .....	9
4.4	Failsafe outputs.....	9
4.4.1	Relay outputs .....	9
4.4.2	Solid state safety outputs .....	10
4.4.2.1	Test pulses.....	10
4.5	AS-Interface bus (AS-i) .....	11
4.5.1	Reading safety slaves .....	11
4.5.2	Slave types.....	12
4.5.3	Modes of operation .....	12
4.5.4	Change of Safety slaves after take in use.....	13
5	Connection of inputs .....	14
5.1	Dynamic signals .....	14
5.1.1	Connection of inputs, I.. .....	14
5.1.2	Connection of in-/outputs IQ.. .....	15
6	Connection of safety devices .....	16
6.1	Dual channel systems .....	16
6.2	Single channel systems .....	17
6.3	Emergency stop .....	17
6.4	Monitoring of external short circuit .....	18
6.5	Safety devices with transistor outputs .....	19
6.6	Safety mats and safety edges .....	19
6.7	Two-hand control .....	20
6.8	Illuminated push button function .....	21
6.9	Monitoring of muting lamp (only A20) .....	21
7	Connection of outputs .....	22
7.1	Connection examples.....	22
8	Example of applications .....	25
9	Pluto bus communication .....	26
9.1	Bus cabling.....	26
9.1.1	Cable length .....	27
9.1.2	Connection of bus cable shield .....	27
9.1.3	Optional protection against conducted disturbances .....	28
9.2	Response time over the bus .....	28
10	Identifier .....	29
11	Programming.....	31
11.1	Self programming by exchange of Pluto .....	31
12	Cleaning .....	32
13	Technical data .....	32
13.1	Connection of sensors .....	35
14	Appendix - Message and fault code list .....	36

# 1 General

Pluto is a programmable safety system intended for safety applications where it is not accepted that faults in the control system lead to loss of a safety function. To achieve this requirement the system is designed with integral redundancy and monitoring. Unlike ordinary PLC systems, Pluto utilizes two microprocessors, which both control and monitor each safety function for correct operation. Each input to the system is separately connected to each processor, each having their own memory and executing their own program. The processors continuously compare the results with each other to ensure integrity of data.

Each safety output is connected to both processors and can not be set unless both have checked that the logic conditions in the application program are fulfilled.

Each Pluto unit has connections for CAN-bus and can be interconnected with other Pluto units. The degree of safety is the same over the bus as it is within each unit.

Pluto is designed for fulfilling the demands of the EU Machinery Directive (98/37/EG) regarding safety of control systems, however the system can be used in other applications such as processing industry, furnaces, railways, etc. which have similar requirements.


Pluto is designed according to the following functional safety standards for control systems:

- EN 954-1, Category 4
- EN 62061, SIL3
- EN 13849-1, Category 4 and Performance level e
- IEC 61508-, SIL 3

## 2 Enclosure

Pluto is constructed in an enclosure for snap mounting on a DIN-rail in control cabinets or other suitable enclosures. External wiring is connected via screw terminals. To make it easy and to avoid incorrect connection when a unit is exchanged, the connector blocks are detachable so that individual wires do not have to be disconnected.

*Note that the power shall be off during connection and disconnection*



## 3 Electrical installation



The system is powered by 24V DC. The system has internal over current protection (PTC) but should be protected by an external fuse. (See technical data)

The Pluto is designed for applications which fulfil IEC-EN 60204-1 and with special attention to:

- “Transformers shall be used for supplying the control circuits”. These transformers shall fulfil EN60742 and EN61588.
- “Where several transformers are used, it is recommended that the windings of those transformers be connected in such a manner that the secondary voltages are in phase”. (see EN 60204-1, 9.1.1)  
These requirements are relevant for connection of the relay outputs.
- For electrical safety reasons and in order to be able to detect safety critical earth faults in single channel circuits, the 0V terminal must be connected to protective bonding circuit. (see EN 60 204-1, 9.4.3.1 Method a).

The system is designed and tested for installation category II according to IEC 61010-1, (all connected circuits are supplied via control voltage transformers).


Cables and connected devices such as sensors, pushbuttons, selector switches shall be isolated for 250V.



*Min. 5 mm space between units.*

## 4 Inputs and outputs

In order to be as flexible as possible Pluto offers various combinations of different I/O: s. There are also different families and types of PLUTO. Pictured below are the IO overview for the various Pluto types.




1) Not S-models, S20,...

2) Current monitored only on A20

*I/O overview PLUTO A20 family*

Inputs and outputs for the A20 family			
Terminal on Pluto	In-/Output name in software	I/O type	Local/Global
I0...I7	I_0...I_7	Safe Input	Global
Q0	Q_0	Safe Output (Relay)	Global
Q1	Q_1	Safe Output (Relay)	Global
Q2	Q_2	Safe Output (Transistor)	Global
Q3	Q_3	Safe Output (Transistor)	Global
IQ10...IQ17	I_10...I_17	Safe Input	Global
	Q_10...Q_17	Nonsafe Output	Local

where “\_” is the Pluto number




1) Not S46-6

*I/O overview PLUTO Double family*

Inputs and outputs for the Double family			
Terminal on Pluto	In-/Output name in software	I/O type	Local/Global
I0...I17	I_0...I_7	Safe Input	Global
I30...I37	I_30...I_37	Safe Input	Local
I40...I47	I_40...I_47	Safe Input	Local
Q0	Q_0	Safe Output (Relay)	Global
Q1	Q_1	Safe Output (Relay)	Global
Q2	Q_2	Safe Output (Transistor)	Global
Q3	Q_3	Safe Output (Transistor)	Global
Q4	Q_4	Safe Output (Relay)	Local
Q5	Q_5	Safe Output (Relay)	Local
IQ10...IQ17	I_10...I_17	Safe Input	Global
	Q_10...Q_17	Nonsafe Output	Local
IQ20...IQ27	I_20...I_27	Safe Input	Local
	Q_20...Q_27	Nonsafe Output	Local


where “\_” is the Pluto number



**I/O overview PLUTO B42 AS-i**

Inputs and outputs for Pluto B42 AS-i			
Terminal on Pluto	In-/Output name in software	I/O type	Local/Global
I0...I3	I_0...I_3	Safe Input	Global
I30...I37	I_30...I_37	Safe Input	Local
I40...I47	I_40...I_47	Safe Input	Local
Q0	Q_0	Safe Output (Relay)	Local
Q1	Q_1	Safe Output (Relay)	Local
Q2	Q_2	Safe Output (Transistor)	Local
Q3	Q_3	Safe Output (Transistor)	Local
Q4	Q_4	Safe Output (Relay)	Local
Q5	Q_5	Safe Output (Relay)	Local
IQ10...IQ17	I_10...I_17	Safe Input	Local
	Q_10...Q_17	Nonsafe Output	
IQ20...IQ27	I_20...I_27	Safe Input	Local
	Q_20...Q_27	Nonsafe Output	
ASi+	-	AS-i bus	-
ASi-	-		

where “\_” is the Pluto number



I/O overview PLUTO AS-i

Inputs and outputs for Pluto AS-i			
Terminal on Pluto	In-/Output name in software	I/O type	Local/Global
I0	I_0	Safe Input	Global
I1...I3	I_1...I_3	Safe Input	Local
Q0	Q_0	Safe Output (Relay)	Global
Q1	Q_1	Safe Output (Relay)	Global
Q2	Q_2	Safe Output (Transistor)	Global
Q3	Q_3	Safe Output (Transistor)	Global
IQ10...IQ13	I_10...I_13	Safe Input	Local
	Q_10...Q_13	Nonsafe Output	Local
ASi+	-	AS-i bus	-
ASi-			


where “\_” is the Pluto number

Pluto AS-i can also read inputs and set outputs in AS-i slaves connected to the AS-i bus. The different slave types are explained further in chapter 4.5.2 Slave types, and the corresponding Pluto configurations for these are explained in the Pluto\_Programming\_Manual.

#### 4.1 I.. Digital failsafe inputs

Each input is separately connected to both processors which, facilitating both single channel and dual channel safety devices.


The inputs can be supplied by +24V or by the dynamic signal outputs A, B or C.



## 4.2 IQ.. Digital failsafe inputs / Digital outputs (non failsafe)

This type of IO-terminals provides 4 different functions. Each terminal is connected to both processors and may therefore be used as a failsafe input.

Each terminal is also equipped with an output transistor giving the user the possibility to configure it as either a failsafe input or non failsafe output. The outputs are intended for functions that do not require redundancy. E.g. indicators and status signals.



### 4.2.1 Dynamic signals

The IQ-terminals can be configured as dynamic outputs A, B or C for supplying inputs. When an output is configured as dynamic, a unique pulse train is generated. A safety input can then be configured just to accept this specific pulse train as input condition and the system will detect external short circuit conditions. (See separate description).

### 4.2.2 Current monitoring IQ16, IQ17 (Only A20)

See 6.9

## 4.3 Analogue inputs


Depending on type there are one or more analogue inputs. These inputs are connected to terminals for digital inputs (example A20 – I5, B46-6 – I5, I6, I7). These analogue inputs are read by both processors and can therefore be used for safety applications.

In the PLC program the value can be read in system registers. See programming manual.

## 4.4 Failsafe outputs

### 4.4.1 Relay outputs

Each potential free relay output is made individually “redundant” by the use of two series connected relay contacts controlled by each processor. A single output can be used to individually control a safety function, however the outputs cannot detect short circuits in e.g. connection cables. In addition to the output relays being controlled by separate processors the power to the relay coils are generated by “charge” pumps. (For description of function of “charge” pump see section on failsafe solid state outputs).



Principle for relay outputs


#### 4.4.2 Solid state safety outputs

Each digital failsafe output is individually safe and can therefore be used to individually control a safety function. The nominal output voltage is  $-24\text{V DC}$ . The negative potential is due to the “charge” pump principle used. The “charge pump” is designed in such a way that the output voltage is generated by a capacitor which is charged and discharged by two transistors. The transistors switch alternately. One transistor switches to plus potential (+), charges the capacitor and then switches off. The other transistor then switches on discharging the capacitor to 0 Volts. During the discharge phase the capacitor “sucks” current from the output making the output a negative voltage. This design principle requires that all components work and change state in the correct phase. A fault in any component leads to an immediate cessation of output current generation.

An advantage of using a negative output potential is that it is not normally present in a control system. Since the output is monitored, Pluto can detect short circuit between the output and a foreign potential.

##### 4.4.2.1 Test pulses

In order to make internal tests and to test against external short circuits the outputs Q2 and Q3 are cyclically switched off during  $100..200\ \mu\text{s}$ , so called test pulses.



Principle for solid state safety outputs.  
Diagram showing output voltage with test pulses


## 4.5 AS-Interface bus (AS-i)

Only for Pluto AS-i and B42 AS-i



As can be seen in the I/O overview Pluto AS-i has only 8 digital I/O but is equipped with connection for AS-i bus. AS-i is a standardised industrial bus where both power and data is transmitted via a two-wire cable. There are two organisations for the standardisation of AS-i, AS-International Association for the general specification and the consortium "Safety At Work" (SAW) for the safety protocol.

This manual does only explain how Pluto AS-i can be used. General information about the AS-i bus is available at <http://www.as-interface.net/>, and in literature as "AS-Interface, The Automation Solution".



### 4.5.1 Reading safety slaves

The main intention with Pluto AS-i is to read and evaluate the safety slaves with its dual CPU. A standard slave can have 4 input variables which are read separately by the master. A safety slave has also 4 input variables, but physically only one single channel or dual channel input. The 4 input variables are used to send a safety code, unique for each slave. The safety code is transmitted in 8 cycles. Pluto reads the safety code, compares it with the code stored in the memory and if they match the input in the safety slave is evaluated as on (1).

A teaching procedure must be performed at installation and exchange of safety slaves in order to teach Pluto the correct code for each safety slave. (See programming manual.)

## 4.5.2 Slave types

Pluto has to be configured for the type of slave(s) that is connected to the AS-i bus. This configuration is done in Pluto Manager and is explained in the Pluto\_Programming\_Manual. Below is a short description of the different slave types that Pluto supports:

### Safe Input

This is a safe slave with a single or dual channel input. For the dual channel type there is physically a dual channel input to the slave, but in Pluto/Pluto Manager it is configured as one input. The slave can also have up to 4 non-safe outputs.

*AS-i profile: S-x.B where x depends on I/O configuration.*

### Nonsafe standard slaves

A non-safe standard slave can have up to 4 non-safe inputs and/or up to 4 non-safe outputs. In Pluto both inputs and outputs are local.

*AS-i profile: S-x.F where x depends on I/O configuration.*

### Nonsafe A/B slaves

Two A/B-slaves (one A-slave + one B-slave) share the same address number. This means that up to 62 A/B-slaves can be used in a net, instead of 31 which is the maximum number for other slave types. A non-safe A/B-slave can have up to 4 inputs and/or up to 3 outputs. In Pluto both inputs and outputs are local.

*AS-i profile: S-x.A where x depends on I/O configuration.*

### Combined Transaction A/B slaves

Pluto supports Combined Transaction slaves with 4 inputs and 4 outputs.

*AS-i profile: S-7.A.7*

### Analogue input slaves

This is a non-safe analogue input slave which can have up to 4 input channels. A special function block is needed for the PLC program.

*Pluto supports Analog slaves with AS-i profile: S-7.3*

### Safe Output

A safe slave has (at this moment) one safe output, and a special function block is needed for the PLC program. This slave is usually combined with a non-safe slave for feedback status. Even if this non-safe slave is included in the same housing as the safe output slave they have different addresses and they are treated as two separate slaves by Pluto. Pluto can handle up to 16 safe output slaves.

## 4.5.3 Modes of operation

Pluto has three modes of operation on the AS-i bus:

### Bus Master

Pluto controls the AS-i bus. Via the PLC program Pluto can read the inputs and set the outputs of the slaves.

### Monitor only

In this case Pluto only listens to the bus traffic, which is controlled by an external master. Normally this external master is a non-safety PLC system for control of the non safety related part of the application.

In monitor mode Pluto can read all I/O:s on the AS-i bus but not set any outputs since it is the external master that controls the bus.

### **Monitor / Slave**

This mode is the same as "Monitor only" mode but Pluto can also be a slave node under the external master. Pluto and the external master can then communicate with each other, 4 bits in each direction.

#### **4.5.4 Change of Safety slaves after take in use**

The system allows exchange of a safety slave without any tool for modification of the PLC program or other setup.

The requirement is that all slaves, except the one that shall be replaced, are working and connected to the AS-i bus. It is also necessary that the IDFIX is of type "IDFIX-DATA" or "IDFIX-PROG".


The procedure is following:

- Press "K" button for 2 seconds.
- If one safety slave is missing the display flashes "CC" -> "[slave number]".
- Press the "K" button one more time to acknowledge and the display will show steady "CC".
- The new safety slave can now be connected and the display will show "CF" (Code found).
- By pressing "K" a last time, Pluto will automatically store the new code and reboot.

## 5 Connection of inputs

### 5.1 Dynamic signals

The IQ terminals can be configured as dynamic outputs, and be used for voltage supply of the input devices. If they are configured as dynamic, each of them generates a unique pulse train as shown in the diagram below.




The system is intended for detection of different short circuits in external cabling, and dynamic monitoring of sensors. It enables the connections of devices such as “SPOT” light beams, EDEN sensors etc. that inverts the input signal.

In the software a configuration of the inputs must be made to decide which kind of input signal each input shall accept as logic “1”. Other signals that do not match with the configured signal are regarded as “0”.

#### 5.1.1 Connection of inputs, I..

Input type I\_ can be connected to; A, B, C, A-inverse, B-inverse, C-inverse or +24V.

The diagram below shows possible connections and how they are configured in the software.




**NOTE:** The connections are only to show how devices can be electrically connected and are **not** to be taken as connections for any specific applications.




## 6 Connection of safety devices

### 6.1 Dual channel systems

The classic way of making a failsafe system is to use two-channel devices. The system offers various possibilities for connection of such devices. The figures below show solutions for connection of two channel devices. The first figure gives example of possible connections and the second shows the common connection of several dual channel safety devices.




*Possible solutions for dual channel inputs with detection of external short circuits*



*A normal connection of several dual channel devices. One dynamic signal combined with static +24V.*

## 6.2 Single channel systems

Instead of using two-channel systems some applications can be made failsafe by using the principle of a dynamic single channel. By supplying electronic devices with dynamic signals a fault in the electronics will lead to a static on or off state at the input which will be detected immediately. By inverting the signal in or at the sensor, short circuits over the sensor are also detected.



**Note:** Serial connection is legal, but a short circuit of an even number of sensors is **not** detected.

A direct connection between two terminals of IQ type is always detected. Detection of a short circuit between an output of IQ and an input of I is **not** detected.


See 13.1 for maximum number of sensors that can be connected in series.

## 6.3 Emergency stop

When emergency stop functions remain inactivated for long periods of time, the function will not be monitored. It is therefore strongly recommended that emergency stop systems are periodically, manually tested and that this forms part of the maintenance instructions for the machine.

## 6.4 Monitoring of external short circuit

The system offers three main methods for avoiding that short circuit in input cabling leads to loss of the safety function. The drawing below illustrates the different methods by which emergency stop buttons can be connected.




- The first button has two NC contacts supplied by one dynamic signal and +24V. The inputs are configured just to accept the expected signal and will therefore detect a short circuit between the channels as well as to other foreign voltage.
- The button in the middle has one NC and one NO contact supplied by +24V. The software requires that the inputs operate in opposition to each other. A short circuit in the connecting cable will have the effect that both inputs will at sometime during the cycle be ON, which the system does not accept.
- The last emergency stop button uses a short circuit proof single channel technique. A dynamic signal is converted by an inverter mounted close to the contact. The input is configured just to accept the inverted result of the supplied dynamic signal. A short circuit in the connecting cable will result in an incorrect signal being presented to the input which will not be accepted by the system.

## 6.5 Safety devices with transistor outputs

Certain safety devices on the market, i.e. light curtains, light beams, scanners etc., are designed with dual monitored safety 24V DC transistor outputs. These devices monitor the output circuits by making short interruptions in the output signals. Both channels can be connected to the system as static inputs. Faults are detected by the safety device instead of by the Pluto system. **But note that at least one of the inputs must be of IO-type I<sub>-</sub>.**


The short interruptions of the output signals are taken care of by the Pluto input filtering system.



**NOTE:** Only one of the inputs may be of the IO-type IQ<sub>-</sub>.

## 6.6 Safety mats and safety edges


Safety mats and safety edges must be supplied by two different dynamic signals and be connected to two inputs. By activation the two inputs will both get wrong input signal and give "0" in the software as result. The programming can be made in the same way as for other dual channel functions.



Connection of safety mats.  
The diodes shall be placed before the mat (as shown).

## 6.7 Two-hand control


Two-hand control devices can be realized in many ways depending on the contact configuration in the two-hand device and which Pluto inputs are used. Below are some examples of solutions. All of the examples shown fulfil the requirements for type IIIC according to EN 574.



*Examples of two-hand control*

## 6.8 Illuminated push button function


It is possible to connect both an indicator lamp and an input switch at the same time to IQ terminals, e.g. illuminated push button. A diode must be connected locally to the input device. The function is mainly intended for reset devices and reduces the number of IQ terminals used.



Note that the output voltage is a square wave of 24 V amplitude and the effective voltage to the indicator is reduced to a mean value of 75%. A filament bulb or LED designed for 24 VDC can be used.

## 6.9 Monitoring of muting lamp (only A20)

The system can measure the current in output IQ16 and IQ17. The function is intended for monitoring the current in a muting lamp, but other usage is not excluded. As the hardware for measuring the current is not fully redundant the function must be used in a dynamic way if used for safety functions. This means that the current must be read and evaluated both when the output is switched on and off.




## 7 Connection of outputs

Below are examples of output connections that give different degrees of protection against short circuits. When and where they can be used depends on the kind of machine application (risk) and the electrical installation.

### 7.1 Connection examples

**Output examples 1:** Connection and monitoring of contactors.




A fault in a contactor will not lead to the loss of the safety function and is monitored since the NC-contacts are connected to an input.

Note: Some short circuits from +24V and -24V can switch on both contactors and lead to loss of the safety function.

The example connections can be used where the highest safety integrity level is not required and the risk for short circuits is low or can be excluded e.g. inside a control cabinet. Example of application is automatic machines where safety function is used by setting, adjustment etc.


## Output examples 2: Contact expansion with expansion relays and safety relay




The examples give the same degree of safety and have the same advantages and disadvantages as output examples 1 and can be used for the same type of applications.

## Output examples 3: Short circuit protected

Connection and monitoring of contactors with protection against short circuit, for applications with very high demands on safety integrity level. (Category 4). In the example using output Q2 the conductor is protected with a shield connected to protective ground. Examples are applications for safeguarding the operator of manual operated machines like presses and press brakes.




### Output example 4: Polarized safety relays



When using a safety relay for output expansion of output Q2 and Q3, the connection between the Pluto output and the safety relay is failsafe against short circuit from foreign +24V. This because it is operated by -24V and since the safety relay is polarized it cannot be switched on by +24V. As long as a -24V potential does not exist in the cabinet (which is not normally the case) the connection is failsafe.

## 8 Example of applications



## 9 Pluto bus communication

Up to 32 Pluto units can be interconnected with CAN-bus. Communication is achieved by connecting a twisted pair cable to the CH and CL terminals. When this connection is made the Pluto units can read each others I/O.


When the bus is connected each Pluto unit executes its own individual program and operates independently, however it can read other units I/O.

An interruption of the bus connection results in the I/O in the unit with which communication is lost, being regarded as a "0" condition by other units on the bus. In this situation all units will continue program execution with the consequences of the fault being dependant upon the application program. For instance, if an emergency stop button connected to one unit is used by another unit as a condition for setting an output, the output will switch off if communications are lost. Outputs generated by I/O connected directly to a unit are not affected by interruption of communications.

### 9.1 Bus cabling

The maximum length of CAN-bus cabling is dependant on the transmission speed. At the default setting of 400 kbit/s the maximum total length is 150 meters. At each end of the bus a termination resistor of 120  $\Omega$  must be installed. When a Pluto unit is working alone and no bus-cable is connected, it must still be equipped with a termination resistor.

The bus connection should be made with a twisted pair cable to the CH and CL terminals.



### 9.1.1 Cable length

The maximum cable length is depending on the bus speed.

Data Rate	Trunk Distance	Stub length Units connected on a Stub must not have termination resistors fitted.	
		Max single stub	Accumulated stub length
100 kbit/s	600 m	25 m	120 m
125 kbit/s	500m	20 m	100 m
200 kbit/s	300m	13 m	70 m
250 kbit/s	250m	10 m	50 m
<b>400 kbit/s</b>	<b>150m</b>	<b>6 m</b>	<b>30 m</b>
500 kbit/s	100m	5 m	25 m
800 kbit/s	50m	3 m	15 m
1 Mbit/s	<20m	1 m	5 m

### 9.1.2 Connection of bus cable shield


It is not clear which is the right solution for connection of the bus cable shield because there are different disturbances that can make influence on the system. In some cases with high disturbances it can be necessary to test different solutions. The figure below shows three alternatives.

**Alternative 1** has shown the best performance since it gives good protection against disturbances along the cable and has not got the disadvantages that alternative 2 and 3 have. If there is a difference in ground potential between the cabinets this solution is recommended to avoid current in the shield.

**Alternative 2** is the common solution giving a good protection against disturbances along the cable but have the disadvantage in that current in the shield can appear and by noisy supply voltage to Pluto it can also give problems.

**Alternative 3** solves the problems with alternative 2 but does not give good protection against high frequency disturbances.


If the Pluto units are mounted close to each other in the same cabinet the shield can be omitted.




Alternatives for connection of bus cable shield

### 9.1.3 Optional protection against conducted disturbances

Conducted disturbances may cause problems with the Pluto bus communication. This problem might be solved by connecting a capacitor between 0V on Pluto Supply and earth. Please note that this connection is optional. It shall only be tried if there is a problem with the bus communication!



Capacitor between 0V and earth.



Example of terminal block with capacitor.

## 9.2 Response time over the bus

As default the system works with the Baud rate set to 400 kbit/s and CAN-cycle to 20 ms. CAN-cycle 20 ms gives 10 ms extra response time for data over the bus (10-40 ms under fault condition). The records under Technical data for response time over bus etc. are related to this. To enable the use of longer cable lengths it is possible to change the baud rate to a lower value, but care must be taken as the bus can be overloaded. To avoid this overload there are two solutions: either to limit the amount of Pluto units connected on the bus or to increase the Bus cycle time which also increases the response time.

Note that "Bus cycle time" is individually set for each Pluto unit which means that it is possible to give variables of some Pluto units, better response times than others. It is also important to note that if an input in one unit controls an output in another, it is regarding the response time only relevant where the input is located. If the "Bus cycle time" in the unit with the output is changed it has no influence on the response time.

The table below is a guideline for selection of bus parameters.

Baud rate \ Bus cycle time	100 kb/s	125 kb/s	200 kb/s	250 kb/s	400 kb/s	500 kb/s	800 kb/s
10 ms	3..4	4..6	8..10	12..14	18..25	25..32	32
20 ms	6..8	10..14	20..32	22..32	32	32	32
30 ms	12..18	15..21	20..32	25..32	32	32	32
40 ms	12..23	20..30	28..32	30..32	32	32	32

Possible number of units connected to the bus.


**NOTE 1:** The exact value for number of units can not be established since it depends on the application. If I/Os in a Pluto unit changes state often it produces more CAN telegrams.

**NOTE 2:** The prolongation of response time for I/O over the bus is equal with the Bus cycle time.

## 10 Identifier

The identifier is an external component that can be connected to the "ID" and "OV" terminals. The circuit contains a unique ID-number that can be read by the system. In the PLC program the identifier number can be declared which connects the program so that it will only work together with the correct identifier. The use of identifier is voluntarily as long as a unit works alone, but if an identifier is connected to the unit and the PLC program is declared to work without, the program will not run.

The function gives a protection against a unit being exchanged by mistake. The identifier circuit should be securely fastened to the physical location of the unit by e.g. tie it together with other connection conductors.



*Connection of identifier*

When a number of Pluto-units are interconnected with the bus, identifiers are necessary. The units are numbered 0...31. In the application program it is necessary to declare which identifier number has to be connected to which Pluto unit (0...31).

Example: ! id\_pluto:01=023474526654

There are several types of identifier circuits available;

### **IDFIX-R** (pre-programmed)

- The number is programmed by the circuit manufacturer who guarantees that two circuits with the same number do not exist.

### **IDFIX-RW** (programmable)

- The number can be programmed by the user.

### **IDFIX-DATA** (programmable & data storage)

- For Pluto AS-i and B42 AS-i.
- The number can be programmed by the user and safety codes of AS-i safe slaves can be stored.

### **IDFIX-PROG** (programmable, data & PLC program storage)

- For Pluto with OS version 2.50 or higher.
- This IDFIX has enough memory to also store the PLC program (maximum size 2.3 kbyte).
- Only one Pluto is allowed in the project, and the IDFIX code is always EEEEEEEEEEE0.
- Can be used to store AS-i safety codes in the same way as IDFIX-DATA.
- When a program is downloaded to Pluto the IDFIX-PROG will automatically be updated.
- If there is a difference between the program in the IDFIX-PROG and the flash memory then Er31 will be displayed and PLC program execution is prohibited. This is checked at program download and at boot time.

- The PLC program in IDFIX-PROG can be loaded into flash memory by pressing the K button in the same way as self programming over the CAN bus. This can be done when Pluto displays error message Er20 (No program loaded), Er24 (Erroneous PLC program) or Er31 (IDFIX-PROG program mismatch).

Programmable identifiers (IDFIX-RW and IDFIX-DATA) can for example be used where it is required to deliver units with the same PLC program e.g. for a special machine or safety application.

# 11 Programming

The development of application programs (Pluto PLC program) is made with a standard Personal Computer using a specially developed software Pluto Manager. Communication between the PC and the Pluto is made via the PC Com Port or USB port. The link facilitates program down loading and monitoring of inputs, outputs, memory, timers, etc. with the PC “on line”.

See separate programming manual for further information.

## 11.1 Self programming by exchange of Pluto

In applications with several Pluto units connected together with the Pluto CAN bus, it is possible to exchange a unit and let it self load PLC program from another Pluto on the bus. This is possible since in a program project with at least two Pluto units, all of them are loaded with the same program file and this file has program for all units.

The following conditions are required:

- The new Pluto must be empty of PLC program (showing Er20).
- The new Pluto must be member in a Pluto program project.
- The IDFIX must NOT be exchanged. (Note that the connector blocks are detachable)
- For Pluto AS-i the IDFIX must be of type “IDFIX-DATA”. (Otherwise the “Teach safety codes” procedure has to be performed as well.)

### Procedure:

- Switch off power and exchange Pluto.
- Switch power on and after a few seconds the display shall show Er20 (empty).
- Press the “K” button in the Pluto front in 3 seconds until the display flashes “Lo”.
- Release the “K” button and press it immediately one more time.  
The display shall show steady “Lo”.
- Now the self programming has started. “K” button can be released, and when it is finished Pluto starts to run automatically.

If flashing “Lo” doesn’t appear:

- Check the CAN bus connection.
- Check that the IDFIX is connected and that it is not changed to another with other number.
- Check that the Pluto really was member in same program project as the other on the Pluto bus.

## 12 Cleaning

The front plate can be cleaned by a dry dust rag. The front plate can also be removed for cleaning or exchange.

## 13 Technical data

### Supply

Nominal Voltage	24 V DC
Tolerance	+/-15%
Max interruption	20 ms

Recommended external fuse	A20, B20, S20, Pluto AS-i: 6A B46-6, S46-6, B42 AS-i: 10A
Own current consumption	A20, B20, S20, Pluto AS-i: 100...300 mA B46(-6), S46(-6), B42 AS-i: 100...500 mA
Electrical installation:	Category II according to IEC 61010-1

### Failsafe inputs

I0, I1, I2, ..	+24V (for PNP sensors)
IQ10, IQ11, ..	+24V (for PNP sensors) also configurable as non-failsafe outputs.
Logic '1'	> 12V
Logic '0'	< 8V

Input current at 24V:	5.1 mA
-----------------------	--------

Max. over voltage	27 V continuously
-------------------	-------------------

### Analogue inputs

Range:	0...27 V
A20 family	Terminal I5
Double family	Terminal I5, I6 and I7
Pluto B42 AS-i	Terminal I1, I2 and I3
Pluto AS-i	Terminal I10, I11, I12 and I13

### Safety output

Q2-Q3:	Solid state, -24V DC, 800mA
Output voltage tolerance:	Supply voltage -1.5V at 800mA

Q0, Q1, (Q4, 5):	Relay, AC-1: 250 V / 1.5 A AC-15: 250 V / 1.5 A DC-1: 50 V / 1.5 A DC-13: 24 V / 1.5 A
------------------	---

### Outputs, non-failsafe

IQ10, IQ11,..	Solid state +24V, PNP open collector Also configurable as failsafe inputs.
Max load/output:	800 mA

Max total load:	
A20, B20, S20	IQ10..17: 2.5 A
B46-6, S46-6, B42 AS-i	IQ10..17: 2 A, IQ20..27: 2A
Pluto AS-i	IQ10..13: 2 A

Current monitoring IQ16, IQ17 (Only Pluto A20)	
Range	0-1.0 A
Accuracy	10%



### Safety parameters

#### Charge pump outputs\*

PFD <sub>AV</sub> (for proof test interval = 20 years)	1.1 x 10 <sup>-4</sup>
SILCL according to EN 62061	SIL 3
PFH <sub>D</sub> according to EN 62061	1.5 x 10 <sup>-9</sup>
SIL according to IEC/EN 61508	SIL 3
MTTF <sub>d</sub> according to EN ISO 13849-1	High/1500 years
PL according to EN ISO 13849-1	PL e
Category according to EN ISO 13849-1	4
DC <sub>avg</sub> according to EN ISO 13849-1	High
CCF according to EN ISO 13849-1	Meets the requirements
Relay outputs*	
PFD <sub>AV</sub> (for proof test interval = 20 years)	1.5 x 10 <sup>-4</sup>
SILCL according to EN 62061	SIL 3
PFH <sub>D</sub> according to EN 62061	2 x 10 <sup>-9</sup>
SIL according to IEC/EN 61508	SIL 3
MTTF <sub>d</sub> according to EN ISO 13849-1	High/1100 years
PL according to EN ISO 13849-1	PL e
Category according to EN ISO 13849-1	4
DC <sub>avg</sub> according to EN ISO 13849-1	High
CCF according to EN ISO 13849-1	Meets the requirements
HFT (Hardware fault tolerance)	1
SFF (Safe failure fraction)	>99% for the single channel parts >90% for the double channel parts

#### Note:

PFD<sub>AV</sub> = Average probability of dangerous failure on demand

PFH<sub>D</sub> = Probability of dangerous failure per hour

MTTF<sub>d</sub> = Mean time to dangerous failure/channel

PL = Performance level (as defined in EN ISO 13849-1)

CCF = Common cause failure

\*Input to output (incl. AS-i and CAN bus)

### 13.1 Connection of sensors

Maximum number of sensors that can be connected in series with 100m cable:

Eden	10
Spot 35	3
Spot 10	1
Tina	10

Maximum cable length without sensors for inputs using dynamic signals (depending on capacitance):

Example  $10 \times 0.75 \text{ mm}^2 = \text{approx. } 1000 \text{ meter}$

# 14 Appendix - Message and fault code list

## Status messages

No:	Description
--	Power up
Nn	Run mode (nn = station number)
Lo	Program load mode state. Flashing "Lo", ready for self programming (program found in other unit)
HA (SR11=7)	Program execution stopped from PC computer or not started after program download. Can be started either from PC or by power off-on.

## User faults

No:	Fault and possible reason.	Reset action
Er10*	Dynamic output short circuited to foreign voltage.	Automatically reset
Er11*	IQ_ for illuminated push button function. Missing diode	Automatically reset
Er12*	Short circuit between two dynamic inputs	Automatically reset
Er13*	Static output Q10..17 (Q20..27) short circuited to 0V or safety Q2,Q3 overloaded	Automatically reset, "K" button
Er14*	Static output Q10..17 (Q20..27) short circuited to 24V.	Automatically reset
Er15	Power supply below 18V	Autom. 3 min or "K" button
Er16	Power supply above 30V	Autom. 3 min or "K" button
Er18	CAN-bus fault. (Short circuit, termination resistor, etc.)	Autom. 3 min or "K" button
Er19	Other unit with same station number on Can-bus	
Er20	PLC-program not loaded	Load of PLC program
Er21	PLC-program CRC-error	Reload with valid PLC-program
Er22	Identifier problem. External identifier can not be read.	Reboot
Er23	Unmatched ID. Identifier doesn't match declaration in program.	Exchange of identifiers or re-declaration of identifier in program.
Er24	Erroneous PLC-code. Invalid PLC-instructions.	Reload with valid code.
Er25	For versions as B16. Non existing output used in program.	
Er26	Baud rate conflict. Unit programmed for other baud rate than current bus baud rate. Note that Pluto must be rebooted after change of baudrate in the PLC program.	Reprogramming or reboot.
Er27	Wrong checksum for unit member in common program.	Reprogramming or reboot
Er28	PLC program does not match the Pluto family. Families: [A/B/S 20, B16], [B/S 46-6], [Pluto AS-i]	Change to other type of Pluto or change the program.
Er29	Unsupported program version. The program contains instructions only supported by later customer specific operating systems.	Update of operating system
Er30	Unsupported function block used	Update of operating system
Er31	IDFIX-PROG program mismatch	Load program to flash memory with "K" button

\*Combined with LED flashing for the affected I/O.

## I/O faults

No:	Fault and possible reason.	Reset action
E r40*	Error safety output Q0 ..5. / Q2,Q3 connected together or to other negative voltage. / Q2,Q3 has to high capacitive load.	"K" button.
E r41*	Error output Q2 or Q3. Overload or connected to foreign positive voltage.	"K" button.
E r42*	Error relay output. No answer from internal relay monitoring when output is off.	"K" button.
Er43*	Error relay output. (Self test of transistors)	Reboot
Er44*	Error relay output. Internal relay does not switch on.	"K" button.
Er45	Analogue functions not calibrated.	System must be calibrated

\*Combined with LED flashing for the affected I/O.

Note: Reboot can either be made from PC computer or by power off-on.

## CPU faults

No:	Fault and possible reason.	Reset action
Er50	Input data difference between processor A and B Processor A and B reads an input differently. The fault is often caused by a bad sensor. Corresponding input LED flashes.	Reboot
Er51	Output data difference between processor A and B. Processor A and B sets a global variable different (Q0..Q3, GM0..11). (The problem can be caused by the PLC-program)	Reboot
Er52	No answer from any internal relay when output is off. (Both relays stuck)	Reboot
Er58	AS-i safety code table CRC error	Reboot, Teach AS-i safety codes
Er59	Calibration analogue functions CRC fault	Reboot
Er60	Twin self test monitoring	Reboot
Er61	Timer IRQ monitoring	Reboot
Er62	Internal serial communication	Reboot
Er63	Boot-flash CRC	Reboot
Er64	OS-flash CRC	Reboot, Reload operating system (OS)
Er65	Plc-flash CRC	Reboot, Reload PLC program
Er66	5 volt under/over voltage monitoring	Reboot
Er67	CPU-test error	Reboot
Er68	Ram-test error	Reboot
Er69	Scan cycle time over run, PLC program too big	Reboot
Er70	System, sum of system and stack monitoring	Reboot
Er71	Pluto used for IDFIX writing. Normal operation ceased	Reboot
Er72	System error. No communication AS-i processor	Reboot
Er73	System error. CRC AS-i processor	Reboot
Er74	Remanent memory error	Reboot

Note: Reboot can either be made from PC computer or by power off-on.

## AS-i

No:	Fault and possible reason.	Reset action
AE 01	ASi power missing	
AE 02	No connection with ASi master (By monitor mode)	
AE 03	Safety code missing by code teaching	
AE 04	Wrong code table	
AE 05	Global communication fault.	
AC [node no]	Channel fault in safety node	Switch off both channels
Ab [node no]	AS-i slave with bad or wrong safety code.	Routine "Single slave exchange" or teach safety codes (PC) or exchange defect slave.
An [node no]	Slave profile does not match.	Read AS-i slaves
CC [node no]	Code Change. Pluto prepared for exchange of safety slave, one slave is missing. (Acknowledge by "K" button.)	
CC	Code Change. Pluto is prepared for connection of new safety slave.	
CF	Code Found. Code in new safety slave is available. (Acknowledge by "K" button.)	

## In-/Output LED's

The status of the Input and Output LED's gives additional information for troubleshooting.

Indication	Fault and possible reason.	Reset action
Double flash	Two-channel fault at use of two-channel function block in the PLC program. Double flash on the channel which has opened.	Open and close both channels.

## EC declaration of conformity

We ABB AB declare that the safety components of ABB  
Jokab Safety manufacture, with type designations and safety  
Boplatsgatan 3 functions as listed below, are in conformity with the  
S-213 76 Malmö Directives  
Sweden 2006/42/EC  
2004/108/EC  
2006/95/EC

Programmable electronic safety system (Safety PLC system) Pluto version A20, B20,  
B16, S19, S20, B46, S46, AS-i, B42 AS-i

<b>Applicable harmonized standards</b>	EN ISO 13849-1:2006/EN 954-1	(Directive 2006/42/EC)
	EN ISO 13849-1:2008	(Directive 2006/42/EC)
	EN ISO 13849-2	(Directive 2006/42/EC)
	EN 62061	(Directive 2006/42/EC)
	EN 61496-1	(Directive 2006/42/EC)
	EN 574	(Directive 2006/42/EC)
	EN 692	(Directive 2006/42/EC)
	EN 60204-1	(Directive 2006/95/EC)
	EN 50178	(Directive 2006/95/EC)
	EN 61000-6-2	(Directive 2004/108/EC)
EN 61000-6-4	(Directive 2004/108/EC)	
EN 61000-4-1...6	(Directive 2004/108/EC)	

**Other applicable  
standards and  
documents** IEC/EN 61508  
DIN V VDE 0801:1990 with amendment A1:1994

**EC Type-Examination** TÜV-Rheinland, Notified body No. 0035

**Certificate no** 01/205/5066/10

**Compiler of technical  
file** Göran Svensson, Kanalvägen 17, 183 30 Täby, Sweden

Kungsbacka 2011-01-01



Mats Linger  
Manager PRU Jokab Safety

# Contact information

## Sweden

### Stockholm

ABB/JOKAB SAFETY  
Kanalvägen 17  
SE-183 30 Täby  
Tel: +46-8-54470740  
Fax: +46-8-54470749  
E-mail: [info@jokabsafety.se](mailto:info@jokabsafety.se)  
Web: [www.jokabsafety.com](http://www.jokabsafety.com)

### Västerås

ABB/JOKAB SAFETY  
Fältmätargatan 16  
SE-721 35 Västerås  
Tel: +46-21-814430  
Fax: +46-21-814439  
E-mail: [info@jokabsafety.se](mailto:info@jokabsafety.se)  
Web: [www.jokabsafety.com](http://www.jokabsafety.com)

### Jönköping

ABB/JOKAB SAFETY  
Mekanikervägen 6  
SE-564 35 Bankeryd  
Tel: +46-36-370460  
Fax: +46-36-370469  
E-mail: [info@jokabsafety.se](mailto:info@jokabsafety.se)  
Web: [www.jokabsafety.com](http://www.jokabsafety.com)

### Malmö

ABB/JOKAB SAFETY  
Boplatsgatan 3  
SE-213 76 Malmö  
Tel: +46-40-671 56 00  
Fax: +46-40-671 56 01  
E-mail: [info@jokabsafety.se](mailto:info@jokabsafety.se)  
Web: [www.jokabsafety.com](http://www.jokabsafety.com)

### Kungsbacka

ABB/JOKAB SAFETY  
Varlabergsvägen 11  
SE-434 91 Kungsbacka  
Tel: +46-300-359 00  
Fax: +46-300-730 8  
E-mail: [info@jokabsafety.se](mailto:info@jokabsafety.se)  
Web: [www.jokabsafety.com](http://www.jokabsafety.com)

## International

### Australia

Sensorplex Pty Ltd  
Tel: +61 (03) 9562-6699  
E-mail: [sales@sensorplex.com](mailto:sales@sensorplex.com)  
web: [www.sensorplex.com/jokab.htm](http://www.sensorplex.com/jokab.htm)

### Austria

Contra GmbH  
Tel: +43 (0)1 278 25 55  
E-mail: [office@contra.at](mailto:office@contra.at)  
Web: [www.contra.at](http://www.contra.at)

### Belgium

JOKAB SAFETY AB, Sweden

### Brazil

ABB Ltda.  
Tel: +55 11 3688-9111  
Web: [www.abb.com.br](http://www.abb.com.br)

### Canada

NCC Electronics LTD.  
Tel: +1 519 735 1106  
E-mail: [sales@nccelectronics.com](mailto:sales@nccelectronics.com)  
Web: [www.jokabsafetyyna.com](http://www.jokabsafetyyna.com)

### China

ABB (China) Limited  
Tel: +86 21 23288888  
Web: [www.abb.com](http://www.abb.com)

### Czech Republic

CONTRA spol. s r.o.  
Tel: +420 5 43 210 046  
E-mail: [contra-brno@contra-brno.cz](mailto:contra-brno@contra-brno.cz)  
Web: [www.contra-brno.cz](http://www.contra-brno.cz)

### Denmark

JOKAB SAFETY DK A/S  
Tel: +45 44 34 14 54  
E-mail: [info@jokabsafety.dk](mailto:info@jokabsafety.dk)  
Web: [www.jokabsafety.dk](http://www.jokabsafety.dk)

### Finland

JUHA-ELEKTRO OY  
Tel: +358 (0) 10 8328 100  
E-mail: [info@juha-elektro.fi](mailto:info@juha-elektro.fi)  
Web: [www.juha-elektro.fi](http://www.juha-elektro.fi)

### France

Jokab Safety France SAS  
Tel: +33 810 08 36 20  
E-mail: [dominique.svennarp@jokabsafety.com](mailto:dominique.svennarp@jokabsafety.com)  
Web: [www.jokabsafety.com](http://www.jokabsafety.com)

### Germany

JOKAB SAFETY (D) GMBH  
Tel: +49 (0) 7424-95865-0  
E-mail: [info@jokabsafety.de](mailto:info@jokabsafety.de)  
Web: [www.jokabsafety.com](http://www.jokabsafety.com)

### DEBRA GMBH (Cologne)

Tel: +49 (0) 2234 – 78898  
E-mail: [info@debra-safety.de](mailto:info@debra-safety.de)  
Web: [www.debra-safety.de](http://www.debra-safety.de)

### Ireland

Pressure Hydraulics Ltd  
Tel: +353 (0) 59 9143601  
E-mail: [rconnolly@pressure-hydraulics.com](mailto:rconnolly@pressure-hydraulics.com)

### Italy

JOKAB SAFETY ITALIA S.R.L  
Tel: +39 039 6880134  
E-mail: [info@jokabsafety.it](mailto:info@jokabsafety.it)  
Web: [www.jokabsafety.com](http://www.jokabsafety.com)

### Korea

Safect Co.,Ltd  
Tel: 82-2-2639-8567/8  
E-mail: [supersensor@empal.com](mailto:supersensor@empal.com)  
Web: [www.jokabsafety.co.kr](http://www.jokabsafety.co.kr)

### Netherlands

Isolectra B.V.  
Tel: +31 (0) 10 - 28 55 285  
E-mail: [industrie@isolectra.nl](mailto:industrie@isolectra.nl)  
Web: [www.isolectra.nl](http://www.isolectra.nl)

### Norway

Automasjon og Sikkerhet  
Tel: +47 33 01 52 20  
E-mail: [aut-sikk@online.no](mailto:aut-sikk@online.no)  
Web: [www.jokabsafety.no](http://www.jokabsafety.no)

### Poland

CONTRA Sp. z o.o.  
Tel: +48 33 857 53 44  
E-mail: [office@contra-polska.pl](mailto:office@contra-polska.pl)  
Web: [www.contra-polska.pl](http://www.contra-polska.pl)

### Portugal

Prosistav Lda  
Tel: +351 (0) 234 397 210  
E-mail: [prosistav@prosistav.pt](mailto:prosistav@prosistav.pt)  
Web: [www.prosistav.pt](http://www.prosistav.pt)

### Singapore/Malaysia

PICS TECHNOLOGIES  
Tel: +65 6744 8018  
Tel: +65 6481 2894  
E-mail: [picstec@pacific.net.sg](mailto:picstec@pacific.net.sg)

### Slovakia

LUCOB spol.s.r.o  
Tel: +421 2 432 921 77  
E-mail: [office@lucob.sk](mailto:office@lucob.sk)  
Web: [www.lucob.sk](http://www.lucob.sk)

### Slovenia

Kolektor Synatec d.o.o.  
Tel: +386 5 37 20 677  
E-mail: [synatec@kolektor.si](mailto:synatec@kolektor.si)  
Web: [www.kolektorsynatec.si](http://www.kolektorsynatec.si)

### Spain

EUROTECH SYSTEMS, S.L.  
Tel: +34 93 634 0101  
E-Mail: [t.vidal@eurotechsys.com](mailto:t.vidal@eurotechsys.com)

### South Africa

ALP - Applied Laser Power  
Tel: +27 (0)12 997 0536  
E-mail: [ghenderson@alpsa.co.za](mailto:ghenderson@alpsa.co.za)  
Web: [www.alpsa.co.za](http://www.alpsa.co.za)

### Switzerland

Mattle Industrieprodukte AG  
Tel: +41 44 938 13 33  
E-mail: [info@mattle-ag.ch](mailto:info@mattle-ag.ch)  
Web: [www.mattle-ag.ch](http://www.mattle-ag.ch)

### Turkey

S-Mikron Elektronik Elektrik Sanayi Taah. Ltd. Şti.  
Tel: +90224 443 52 33

### United Kingdom

ABB Ltd/JOKAB SAFETY UK  
Tel: +44 (0) 1908 261595  
E-mail: [info@jokabsafety.co.uk](mailto:info@jokabsafety.co.uk)  
Web: [www.jokabsafety.com](http://www.jokabsafety.com)

### USA/Mexico

JOKAB SAFETY North America  
Tel: +1 734 595 6087  
E-mail: [sales@jokabsafetyyna.com](mailto:sales@jokabsafetyyna.com)  
Web: [www.jokabsafetyyna.com](http://www.jokabsafetyyna.com)